

an extension field set omits the values of any attributes, the values of these attributes SHALL remain unchanged. If an extension field set would cause an unknown or missing attribute to be set for any reason, that attribute SHALL be skipped. The status SHALL be SUCCESS.

4. If the RecallScene command was received as a unicast, the server SHALL then generate a response with the Status field set to the evaluated status.

If the TransitionTime data field is present in the command and its value is not equal to null, this field SHALL indicate the transition time in milliseconds. In all other cases (command data field not present or value equal to null), the SceneTransitionTime field of the Scene Table entry SHALL indicate the transition time. The transition time determines how long the transition takes from the old cluster state to the new cluster state. It is recommended that, where possible (e.g., it is not possible for attributes with Boolean data type), a gradual transition SHOULD take place from the old to the new state over this time. However, the exact transition algorithm is implementation-defined.

1.4.9.13. GetSceneMembership Command

This command can be used to get the used scene identifiers within a certain group, for the endpoint that implements this cluster.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	GroupID	group-id	all			M

1.4.9.13.1. GroupID Field

This field SHALL indicate the group identifier in the Group Table.

1.4.9.13.2. Effect on Receipt

On receipt of this command, the server SHALL perform the following procedure:

1. If the value of the GroupID field is non-zero, the server verifies that the endpoint has an entry for that GroupID in the Group Table. If there is no such entry in the Group Table, the status SHALL be INVALID_COMMAND and the server continues from step 3.
2. The status SHALL be SUCCESS.
3. If the GetSceneMembership command was received as a unicast, the server SHALL then generate a GetSceneMembershipResponse command with the Status field set to the evaluated status.

1.4.9.14. GetSceneMembershipResponse Command

This command is sent in response to the [GetSceneMembership](#) command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	status	desc			M
1	Capacity	uint8	all	X		M
2	GroupID	group-id	all			M