

1.6.7.2.2. Rate Field

This field SHALL indicate the rate of movement in units per second. The actual rate of movement SHOULD be as close to this rate as the device is able. If the Rate field is null, then the value of the DefaultMoveRate attribute SHALL be used if that attribute is supported and its value is not null. If the Rate field is null and the DefaultMoveRate attribute is either not supported or set to null, then the device SHOULD move as fast as it is able. If the device is not able to move at a variable rate, this field MAY be disregarded.

1.6.7.2.3. Effect on Receipt

On receipt of this command, if the Rate field has a value of zero, the command has no effect and a response SHALL be returned with the status code set to INVALID_COMMAND.

Otherwise, a device SHALL first create and process a temporary Options bitmap as described in the [MoveToLevel](#) command.

On receipt of this command, a device SHALL move from its current level in an up or down direction in a continuous fashion, as detailed below.

MoveMode	Action on Receipt
Up	Increase the device's level at the rate given in the Rate field. If the level reaches the maximum allowed for the device, stop.
Down	Decrease the device's level at the rate given in the Rate field. If the level reaches the minimum allowed for the device, stop.

1.6.7.3. Step Command

This command will do a relative step change of the device using the specified values.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	StepMode	StepModeEnum	desc			M
1	StepSize	uint8	all			M
2	Transition-Time	uint16	all	X		M
3	Options-Mask	Options-Bitmap	desc			M
4	OptionsOverride	Options-Bitmap	desc			M

1.6.7.3.1. StepMode Field

This field SHALL be one of the non-reserved values in [StepModeEnum](#).