

1.6.7.3.2. StepSize Field

This field SHALL indicate the change to CurrentLevel.

1.6.7.3.3. TransitionTime Field

This field SHALL indicate the time that SHALL be taken to perform the step, in tenths of a second. A step is a change in the CurrentLevel of StepSize units. The actual time taken SHOULD be as close to this as the device is able. If the TransitionTime field is equal to null, the device SHOULD move as fast as it is able.

If the device is not able to move at a variable rate, the TransitionTime field MAY be disregarded.

1.6.7.3.4. Effect on Receipt

On receipt of this command, if the StepSize field has a value of zero, the command has no effect and a response SHALL be returned with the status code set to INVALID_COMMAND.

Otherwise, a device SHALL first create and process a temporary Options bitmap as described in the [MoveToLevel](#) command.

On receipt of this command, a device SHALL move from its current level in an up or down direction as detailed below.

StepMode	Action on Receipt
Up	Increase CurrentLevel by StepSize units, or until it reaches the maximum level allowed for the device if this reached in the process. In the latter case, the transition time SHALL be proportionally reduced.
Down	Decrease CurrentLevel by StepSize units, or until it reaches the minimum level allowed for the device if this reached in the process. In the latter case, the transition time SHALL be proportionally reduced.

1.6.7.4. Stop Command

This command will stop the actions of various other commands that are still in progress.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Options-Mask	Options-Bitmap	desc			M
1	OptionsOverride	Options-Bitmap	desc			M