

1.13.6.5.1. PreviousPosition Field

This field SHALL indicate the previous value of the CurrentPosition attribute, i.e. just prior to release.

1.13.6.6. MultiPressOngoing Event

If the server has the Action Switch (AS) feature flag set, this event SHALL NOT be generated at all. Otherwise, the following paragraphs describe the situations where this event is generated.

This event SHALL be generated to indicate how many times the momentary switch has been pressed in a multi-press sequence, *during* that sequence. See [Section 1.13.8, “Sequence of events for MultiPress”](#).

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NewPosition	uint8	0 to (NumberOfPositions - 1)			M
1	CurrentNumberOfPressesCounted	uint8	2 to MultiPressMax			M

1.13.6.6.1. NewPosition Field

This field SHALL indicate the new value of the CurrentPosition attribute, i.e. while pressed.

1.13.6.6.2. CurrentNumberOfPressesCounted Field

This field SHALL contain:

- a value of 2 when the second press of a multi-press sequence has been detected,
- a value of 3 when the third press of a multi-press sequence has been detected,
- a value of N when the Nth press of a multi-press sequence has been detected.

1.13.6.7. MultiPressComplete Event

This event SHALL be generated to indicate how many times the momentary switch has been pressed in a multi-press sequence, after it has been detected that the sequence has *ended*. See [Section 1.13.8, “Sequence of events for MultiPress”](#).

The data of this event SHALL contain the following information: