

| ID     | Name                    | Type                                  | Constraint | Quality | Fallback | Access | Conformance |
|--------|-------------------------|---------------------------------------|------------|---------|----------|--------|-------------|
| 0x0000 | <b>Messages</b>         | list[ <a href="#">MessageStruct</a> ] | max 8      |         |          | R V F  | M           |
| 0x0001 | <b>ActiveMessageIDs</b> | list[ <a href="#">MessageID</a> ]     | max 8      |         |          | R V    | M           |

#### 1.16.6.1. Messages Attribute

This attribute SHALL indicate a list of queued messages.

In addition to filtering based upon fabric, to preserve user privacy, the server MAY further limit the set of messages returned in a read request. At minimum, the server SHALL return to a client those messages that the client itself created/submitted.

#### 1.16.6.2. ActiveMessageIDs Attribute

This attribute SHALL indicate a list of the [MessageIDs](#) of the [Messages](#) currently being presented. If this list is empty, no messages are currently being presented.

This list SHALL NOT be fabric-scoped; it SHALL contain [MessageIDs](#) for all [Messages](#) being presented, no matter what fabric the client that queued them is on.

### 1.16.7. Commands

| ID   | Name                          | Direction       | Response | Access | Conformance |
|------|-------------------------------|-----------------|----------|--------|-------------|
| 0x00 | <b>PresentMessagesRequest</b> | client ⇒ server | Y        | O F    | M           |
| 0x01 | <b>CancelMessagesRequest</b>  | client ⇒ server | Y        | O F    | M           |

#### 1.16.7.1. PresentMessagesRequest Command

Upon receipt, this SHALL cause the [message](#) in the passed fields to be appended to the [Messages](#) attribute.

If appending the message would cause the number of messages to be greater than the capacity of the list, the device SHALL NOT append any message to [Messages](#), and SHALL return a status code of RESOURCE\_EXHAUSTED.

When displaying a message in response to this command, an indication (ex. visual) of the origin node of the command SHALL be provided. This could be in the form of a friendly name label which uniquely identifies the node to the user. This friendly name label is typically assigned by the Matter Admin at the time of commissioning and, when it's a device, is often editable by the user. It might be a combination of a company name and friendly name, for example, "Acme" or "Acme Streaming Service on Alice's Phone".