

edArea, the server MAY use StatusText to indicate which areas are unsupported.

If the Status field is not set to Success, or UnsupportedArea, the StatusText field SHALL include a vendor-defined error description which can be used to explain the error to the user. For example, if the Status field is set to InvalidInMode, the StatusText field SHOULD indicate why the request is not allowed, given the current mode of the device, which MAY involve other clusters.

1.17.7.3. SkipArea Command

This command is used to skip the given area, and to attempt operating at other areas on the SupportedAreas attribute list.

On receipt of this command the device SHALL respond with a SkipAreaResponse command.

This command SHALL have the following data fields:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	SkippedArea	uint32	desc			M

1.17.7.3.1. SkippedArea Field

The SkippedArea field indicates the area to be skipped.

The SkippedArea field SHALL match an entry in the SupportedAreas list.

1.17.7.3.2. Effect on Receipt

If the SelectedAreas attribute is empty, the SkipAreaResponse command’s Status field SHALL indicate InvalidAreaList.

If the SkippedArea field does not match an entry in the SupportedAreas attribute, the SkipAreaResponse command’s Status field SHALL indicate InvalidSkippedArea.

If the SkipArea command can not be handled by the device, e.g. due to the current state, the SkipAreaResponse command’s Status field SHALL indicate InvalidInMode.

Otherwise, if the device accepts the request, the device SHALL return a SkipAreaResponse with the Status field set to Success and:

- If the device is currently operating at the area identified by SkippedArea, as indicated by either the CurrentArea or the Progress attributes, if implemented, the device SHALL stop operating at that area.
- If the Progress attribute is implemented, the entry corresponding to SkippedArea SHALL be updated to indicate that the area was skipped.
- The device SHALL attempt to operate only at the areas in the SelectedAreas attribute list where operating has not been skipped or completed, using a vendor defined order.
- If the device has either skipped or completed operating at all areas on the SelectedAreas