

ID	Name
0x0404	Flow Measurement

2.5.4. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Measured-Value	uint16	MinMeasuredValue to MaxMeasuredValue	P X		R V	M
0x0001	MinMeasured-Value	uint16	max 65533	X		R V	M
0x0002	MaxMeasured-Value	uint16	min (Min-Measured-Value + 1)	X		R V	M
0x0003	Tolerance	uint16	max 2048		0	R V	O

2.5.4.1. MeasuredValue Attribute

This attribute SHALL indicate the flow in m³/h as follows:

MeasuredValue = 10 x Flow

The null value indicates that the flow measurement is unknown, otherwise the range SHALL be as described in [Measured Value](#).

2.5.4.2. MinMeasuredValue Attribute

This attribute SHALL indicate the minimum value of MeasuredValue that can be measured. See [Measured Value](#) for more details.

The null value indicates that the value is not available.

2.5.4.3. MaxMeasuredValue Attribute

This attribute SHALL indicate the maximum value of MeasuredValue that can be measured. See [Measured Value](#) for more details.

The null value indicates that the value is not available.

2.5.4.4. Tolerance Attribute

See [Measured Value](#).