

2.13.5.3.10. MinSystime Field

This field SHALL be the measurement time since boot of the value in the [Min](#) field was measured.

This field SHALL be greater than or equal to the value of the [StartSystime](#) field.

This field SHALL be less than or equal to the value of the [EndSystime](#) field.

2.13.5.3.11. MaxSystime Field

This field SHALL be the measurement time since boot of the value in the [Max](#) field.

This field SHALL be greater than or equal to the value of the [StartSystime](#) field.

This field SHALL be less than or equal to the value of the [EndSystime](#) field.

2.13.5.4. HarmonicMeasurementStruct Type

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	Order	uint8	min 1				M
1	Measurement	int64	-2^{62} to 2^{62}	X			M

2.13.5.4.1. Order Field

This field SHALL be the order of the harmonic being measured. Typically this is an odd number, but servers may choose to report even harmonics.

2.13.5.4.2. Measurement Field

This field SHALL be the measured value for the given harmonic order.

For the [Harmonic Currents](#) attribute, this value is the most recently measured harmonic current reading in milliamps (mA). A positive value indicates that the measured harmonic current is positive, and a negative value indicates that the measured harmonic current is negative.

For the [Harmonic Phases](#) attribute, this value is the most recent phase of the given harmonic order in millidegrees (mDeg). A positive value indicates that the measured phase is leading, and a negative value indicates that the measured phase is lagging.

If this measurement is not currently available, a value of null SHALL be returned.

2.13.6. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Power-Mode	Power-ModeEnum				R V	M