

opaque interior.

2.14.5.8. ZoneInformationStruct Type

This struct is used to encode basic information about a Zone without containing the specifics of how the zone is defined.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	ZoneID	ZoneID	all				M
1	ZoneType	ZoneTypeEnum	all				M
2	Zone-Source	Zone-SourceEnum	all				M
3	TwoD-Cartesian-Zone	TwoD-Cartesian-ZoneStruct	all				TWOD-CART & (ZoneType == TwoD-CARTZone)

2.14.5.8.1. ZoneID Field

This field SHALL indicate the unique ZoneID of the Zone.

2.14.5.8.2. ZoneType Field

This field SHALL indicate the zone type which defines the Zone.

2.14.5.8.3. ZoneSource Field

This field SHALL indicate the source of the Zone.

2.14.5.8.4. TwoDCartesianZone Field

This field SHALL indicate the detailed information for the TwoDCartesianZone.

2.14.5.9. ZoneTriggerControlStruct Type

This struct is used to encode a set of values for controlling the generation of [ZoneTriggered](#) and [ZoneStopped](#) events from the Node.

Zone events can be triggered due to many underlying reasons, such as a motion sensor on the device, and this is intended to be manufacturer-specific. When a triggering activity is initially detected, the Node SHALL generate a [ZoneTriggered](#) event.

This places the Node in a triggered state, at which point the Node SHALL internally track two values.