

fied, but it cannot be deleted.

4.3.8.25. PresetTypeStruct Type

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	PresetScenario	PresetScenarioEnum	all				M
1	NumberOfPresets	uint8	all		0		M
2	PresetTypeFeatures	PresetTypeFeaturesBitmap	all		0		M

4.3.8.25.1. PresetScenario Field

This field SHALL specify a [PresetScenarioEnum](#) value supported by this thermostat.

4.3.8.25.2. NumberOfPresets Field

This field SHALL specify a limit for the number of presets for this [PresetScenarioEnum](#).

4.3.8.25.3. PresetTypeFeatures Field

This field SHALL specify a bitmap of features for this [PresetTypeStruct](#).

4.3.8.26. WeeklyScheduleTransitionStruct Type

This represents a single transition in a Thermostat schedule

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	TransitionTime	uint16	max 1439				M
1	HeatSetpoint	temperature	all	X			M
2	CoolSetpoint	temperature	all	X			M

4.3.8.26.1. TransitionTime Field

This field SHALL represent the start time of the schedule transition during the associated day. The time will be represented by a 16 bits unsigned integer to designate the minutes since midnight. For example, 6am will be represented by 360 minutes since midnight and 11:30pm will be represented by 1410 minutes since midnight.