

4.3.8.26.2. HeatSetpoint Field

This field SHALL represent the heat setpoint to be applied at this associated transition start time.

4.3.8.26.3. CoolSetpoint Field

This field SHALL represent the cool setpoint to be applied at this associated transition start time.

4.3.8.27. ScheduleStruct Type

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	Schedule-Handle	octstr	max 16	X			M
1	System-Mode	System-ModeEnum	desc				M
2	Name	string	max 64				O
3	Pre-setHandle	octstr	max 16				O
4	Transitions	list[ScheduleTransitionStruct]	1 to NumberOfScheduleTransitions		empty		M
5	BuiltIn	bool	all	X	false		M

4.3.8.27.1. ScheduleHandle Field

This field SHALL indicate a device generated identifier for this schedule. It SHALL be unique on the device, and SHALL NOT be reused after the associated schedule has been deleted.

This field SHALL only be null when the encompassing [ScheduleStruct](#) is appended to the [Schedules](#) attribute for the purpose of creating a new Schedule. Refer to [Schedules](#) for the creation of Schedule handles.

4.3.8.27.2. SystemMode Field

This field SHALL specify the default thermostat system mode for [transitions](#) in this schedule. The only valid values for this field SHALL be Auto, Heat, and Cool.

4.3.8.27.3. Name Field

This field SHALL specify a name for the [ScheduleStruct](#).

4.3.8.27.4. PresetHandle Field

This field SHALL indicate the default [PresetHandle](#) value for [transitions](#) in this schedule.