

Refer to [Setpoint Limits](#) for constraints

4.3.9.8. AbsMaxCoolSetpointLimit Attribute

This attribute SHALL indicate the absolute maximum level that the cooling setpoint MAY be set to. This is a limitation imposed by the manufacturer.

Refer to [Setpoint Limits](#) for constraints

4.3.9.9. PICoolingDemand Attribute

This attribute SHALL indicate the level of cooling demanded by the PI (proportional integral) control loop in use by the thermostat (if any), in percent. This value is 0 when the thermostat is in “off” or “heating” mode.

This attribute is reported regularly and MAY be used to control a cooling device.

4.3.9.10. PIHeatingDemand Attribute

This attribute SHALL indicate the level of heating demanded by the PI loop in percent. This value is 0 when the thermostat is in “off” or “cooling” mode.

This attribute is reported regularly and MAY be used to control a heating device.

4.3.9.11. HVACSystemTypeConfiguration Attribute

This attribute SHALL indicate the HVAC system type controlled by the thermostat. If the thermostat uses physical DIP switches to set these parameters, this information SHALL be available read-only from the DIP switches. If these parameters are set via software, there SHALL be read/write access in order to provide remote programming capability.

4.3.9.12. LocalTemperatureCalibration Attribute

This attribute SHALL indicate the offset the Thermostat server SHALL make to the measured temperature (locally or remotely) to adjust the [Calculated Local Temperature](#) prior to using, displaying or reporting it.

The purpose of this attribute is to adjust the calibration of the Thermostat server per the user’s preferences (e.g., to match if there are multiple servers displaying different values for the same HVAC area) or compensate for variability amongst temperature sensors.

If a Thermostat client attempts to write [LocalTemperatureCalibration](#) attribute to an unsupported value (e.g., out of the range supported by the Thermostat server), the Thermostat server SHALL respond with a status of SUCCESS and set the value of [LocalTemperatureCalibration](#) to the upper or lower limit reached.

NOTE

Prior to revision 8 of this cluster specification the value of this attribute was constrained to a range of -2.5°C to 2.5°C.