

= 0) is included as a step value.

4.4.7.1.4. When Generated

A client sends this command to change the speed-oriented attributes up or down in a step by step fashion.

4.4.7.1.5. Effect Upon Receipt

The successful receipt of this command could result in one or more of the speed-oriented attributes, FanMode, PercentSetting, or SpeedSetting, to change.

- This command SHALL be executed even if the speed-oriented attributes are not currently at an implemented step value.
- If the Direction field is Increase,
 - If the speed-oriented attributes are lower than the highest step value, the speed-oriented attributes SHALL change to the lowest step value that is higher than the current speed-oriented attributes.
 - Else if Wrap is TRUE, the speed-oriented attributes SHALL change to the lowest step value.
 - Else the speed-oriented attributes SHALL change to (or remain at) the highest step value.
- If the Direction field is Decrease,
 - If the speed-oriented attributes are higher than the lowest step value, the speed-oriented attributes SHALL change to the highest step value that is lower than the current speed-oriented attributes.
 - Else if Wrap is TRUE, the speed-oriented attributes SHALL change to the highest step value.
 - Else the speed-oriented attributes SHALL change to (or remain at) the lowest step value.
- Although the effect of the Step command is implementation specific, the effect on receipt of the Step command SHALL adhere to the conformance of the affected attributes.

4.5. Thermostat User Interface Configuration Cluster

This cluster provides an interface to allow configuration of the user interface for a thermostat, or a thermostat controller device, that supports a keypad and LCD screen.

4.5.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Mandatory global ClusterRevision attribute added