

Name	Keypad*	Remote*	RFID*
Privacy	N	N	N
NoRemoteLockUnlock	Y	N	Y
Passage	N/A	N/A	N/A

* Interface Operational: Yes, No or N/A

NOTE

For modes that disable the remote interface, the door lock SHALL respond to Lock, Unlock, Toggle, and Unlock with Timeout commands with a response status Failure and not take the action requested by those commands. The door lock SHALL NOT disable the radio or otherwise unbind or leave the network. It SHALL still respond to all other commands and requests.

5.2.6.15.1. Normal Value

The lock operates normally. All interfaces are enabled.

5.2.6.15.2. Vacation Value

Only remote interaction is enabled. The keypad SHALL only be operable by the master user.

5.2.6.15.3. Privacy Value

This mode is only possible if the door is locked. Manual unlocking changes the mode to Normal operating mode. All external interaction with the door lock is disabled. This mode is intended to be used so that users, presumably inside the property, will have control over the entrance.

5.2.6.15.4. NoRemoteLockUnlock Value

This mode only disables remote interaction with the lock. This does not apply to any remote proprietary means of communication. It specifically applies to the Lock, Unlock, Toggle, and Unlock with Timeout Commands.

5.2.6.15.5. Passage Value

The lock is open or can be opened or closed at will without the use of a Keypad or other means of user validation (e.g. a lock for a business during work hours).

5.2.6.16. OperationSourceEnum Type

This data type is derived from enum8.

This enumeration SHALL indicate the source of the Lock/Unlock or user change operation performed.