

5.2.9.21. LEDSettings Attribute

This attribute SHALL indicate the settings for the LED support, as defined by [LEDSettingEnum](#).

5.2.9.22. AutoRelockTime Attribute

This attribute SHALL indicate the number of seconds to wait after unlocking a lock before it automatically locks again. 0=disabled. If set, unlock operations from any source will be timed. For one time unlock with timeout use the specific command.

5.2.9.23. SoundVolume Attribute

This attribute SHALL indicate the sound volume on a door lock as defined by [SoundVolumeEnum](#).

5.2.9.24. OperatingMode Attribute

This attribute SHALL indicate the current operating mode of the lock as defined in [OperatingModeEnum](#).

5.2.9.25. SupportedOperatingModes Attribute

This attribute SHALL contain a bitmap with all operating bits of the OperatingMode attribute supported by the lock.

A bit position set to zero SHALL indicate that the mode is supported. A bit position set to one SHALL indicate that the mode is not supported.

Any bit that is not yet defined in [OperatingModesBitmap](#) SHALL be set to 1.

The values considered valid to read or write in the OperatingMode attribute SHALL be the enum values from [DoorLockOperatingModeEnum](#) whose equivalent same-named bit from [OperatingModesBitmap](#) is set to zero in this attribute. WARNING: This is the opposite of most other semantically similar bitmaps in this specification.

5.2.9.26. DefaultConfigurationRegister Attribute

This attribute SHALL represent the default configurations as they are physically set on the device (example: hardware dip switch setting, etc...) and represents the default setting for some of the attributes within this cluster (for example: LED, Auto Lock, Sound Volume, and Operating Mode attributes).

This is a read-only attribute and is intended to allow clients to determine what changes MAY need to be made without having to query all the included attributes. It MAY be beneficial for the clients to know what the device's original settings were in the event that the device needs to be restored to factory default settings.

If the Client device would like to query and modify the door lock server's operating settings, it SHOULD send read and write attribute requests to the specific attributes.

For example, the Sound Volume attribute default value is Silent Mode. However, it is possible that the current Sound Volume is High Volume. Therefore, if the client wants to query/modify the cur-