

COMMAND, etc.) as needed otherwise the [GetUserResponse Command](#) SHALL be sent implying a status of SUCCESS.

5.2.10.34. GetUserResponse Command

Returns the user for the specified UserIndex.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UserIndex	uint16	1 to NumberOfTotalUsersSupported			M
1	UserName	string	max 10	X		M
2	UserUniqueID	uint32	all	X		M
3	UserStatus	UserStatusEnum	all	X		M
4	UserType	UserTypeEnum	all	X		M
5	CredentialRule	CredentialRuleEnum	desc	X		M
6	Credentials	list[CredentialStruct]	0 to NumberOfCredentialsSupportedPerUser	X		M
7	CreatorFabricIndex	fabric-idx	all	X		M
8	LastModifiedFabricIndex	fabric-idx	all	X		M
9	NextUserIndex	uint16	1 to NumberOfTotalUsersSupported	X		M

If the requested UserIndex is valid and the UserStatus is Available for the requested UserIndex then UserName, UserUniqueID, UserStatus, UserType, CredentialRule, Credentials, CreatorFabricIndex, and LastModifiedFabricIndex SHALL all be null in the response.

5.2.10.34.1. UserIndex Field

This field SHALL indicate the user ID.