

| Value | Name                | Summary                | Conformance |
|-------|---------------------|------------------------|-------------|
| 9     | <b>RightInside</b>  | Right inside overflow  | M           |
| 10    | <b>RightOutside</b> | Right outside overflow | M           |

The following table provides a description detailing the enumeration values:

| Value | Name                 | Description                                                                                 |
|-------|----------------------|---------------------------------------------------------------------------------------------|
| 1     | <b>Inside</b>        | The panel opens inward, pivoting from the outside toward the interior side.                 |
| 2     | <b>Outside</b>       | The panel opens outward, pivoting from the inside away from the interior side.              |
| 3     | <b>TopInside</b>     | The panel pivots along its top edge, opening inward towards the interior of the room.       |
| 4     | <b>TopOutside</b>    | The panel pivots along its top edge, opening outward away from the interior of the room.    |
| 5     | <b>BottomInside</b>  | The panel pivots along its bottom edge, opening inward towards the interior of the room.    |
| 6     | <b>BottomOutside</b> | The panel pivots along its bottom edge, opening outward away from the interior of the room. |
| 7     | <b>LeftInside</b>    | The left-hung panel opens inward, pivoting from the right towards the interior of the room. |
| 8     | <b>LeftOutside</b>   | The panel opens outward, pivoting from the right towards the exterior of the building.      |
| 9     | <b>RightInside</b>   | The right-hung panel opens inward, pivoting from the left towards the interior of the room. |
| 10    | <b>RightOutside</b>  | The panel opens outward, pivoting from the left towards the exterior of the building.       |