

Some examples to express the 360 degrees range:

- 0 to 359 degrees
- -180 to 179 degrees
- -90 to 269 degrees

Values in degrees can also be used to express the orientation range of slats even if slats filter a vertical closure such as vertical blinds or a horizontal closure such as a bioclimatic pergola or venetian blinds. The 0° value orientation is the value corresponding to the perpendicular axis to the Closure panel and means that all slats are parallel and offer the maximum opening.

Horizontal Slats:

- Negative values indicate that the user-facing edge is higher than the opposing edge.
- Positive values indicate that the user-facing edge is lower than the opposing edge.

Vertical Slats:

- Negative values indicate that the user-facing edge is to the left of the opposing edge.
- Positive values indicate that the user-facing edge is to the right of the opposing edge.

For example :

Slats travel range	Min Value	Max Value
0°/90° slats travel	0	90
-90°/90° slats travel	-90	90
-30°/90° slats travel	-30	90

5.5.7.7. LimitRange Attribute

This attribute SHALL indicate the range of possible values for the Position field in the [CurrentState](#) attribute.

This range MAY evolve dynamically.

LimitRange.Min and **LimitRange.Max** SHALL be equal to an integer multiple of the Resolution attribute.

5.5.7.8. TranslationDirection Attribute

This attribute SHALL indicate the direction of the translation.

A properly configured closure dimension SHOULD reflect as best as possible the translation as seen by the user. This attribute is not supposed to change once the installation is finalized.

5.5.7.9. RotationAxis Attribute

This attribute SHALL indicate the axis of the rotation.