

the command SHALL return a status code of INVALID_IN_STATE.

If all field values in the command match the corresponding field values in [CurrentState](#), the command SHALL have no effect.

Otherwise, the [TargetState](#) attribute SHALL be updated with the new values for Position, Latch and/or Speed, and a status code of SUCCESS SHALL be returned.

5.5.8.1.5. Impact of Unit(UT) feature

The Unit (UT) feature defines the relationship between the physical unit range (e.g., millimeters, degrees) and the normalized percent100ths value. This allows clients to convert native unit values into percentage values for commands and attribute updates.

The mapping is as follows:

- The Min field of the ["Range"](#) attribute corresponds to 0.00%.
- The Max field of the ["Range"](#) attribute corresponds to 100.00%.

The formulas below show how to perform this conversion.

5.5.8.1.5.1. Specific case of Degrees

In case of Slat orientation with range -90°/90°, both 0.00% and 100.00% target value create a Closed Position. This is the only accepted exception.

Example of Closure Dimension used for Modulation feature with Slats orientation type for different types of range.

Min in degrees	Max in degrees	Needed value in degrees	Request Target value in %
0°	90°	0°	0%
		45°	50%
		90°	100%
-90°	90°	-90°	0%
		-45°	25%
		0°	50%
		45°	75%
		90°	100%
-30°	90°	-30°	0%
		0°	25%
		30°	50%
		60°	75%
		90°	100%