

- If the Direction field is set to Decrease, the Position field of the TargetState attribute SHALL be set to: $\text{TargetState.Position} = \text{CurrentState.Position} - \text{NumberOfSteps} * \text{StepValue}$ and the value SHALL be clamped to 0.00% if the Limitation feature is not supported or LimitRange.Min if the Limitation feature is supported.
- If the Direction field is set to Increase, the Position field of the TargetState attribute SHALL be set to: $\text{TargetState.Position} = \text{CurrentState.Position} + \text{NumberOfSteps} * \text{StepValue}$ and the value SHALL be clamped to 100.00% if the Limitation feature is not supported or LimitRange.Max if the Limitation feature is supported.
- If the Speed field of the command is present, the Speed field of the TargetState attribute SHALL be set to the Speed field of the command, otherwise the Speed field of the TargetState attribute SHALL remain unchanged.