

the Video Player device, may implement the cluster server for this cluster to simplify account login for its users.

6.2.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Initial revision
2	Add support for 8 character Passcode in GetSetupPIN and Login, Add Node to Login, Logout commands. Add LoggedOut event.

6.2.2. Classification

Hierarchy	Role	Scope	PICS Code
Base	Application	Endpoint	ALOGIN

6.2.3. Cluster ID

ID	Name
0x050E	Account Login

6.2.4. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	GetSetupPIN	client ⇒ server	GetSetupPIN-Response	A F T	M
0x01	GetSetupPIN-Response	client ⇐ server	N	F	M
0x02	Login	client ⇒ server	Y	A F T	M
0x03	Logout	client ⇒ server	Y	O F T	M

6.2.4.1. GetSetupPIN Command

The purpose of this command is to determine if the active user account of the given Content App matches the active user account of a given Commissionee, and when it does, return a Setup PIN which can be used for password-authenticated session establishment (PASE) with the Commissionee.

For example, a Video Player with a Content App Platform may invoke this command on one of its Content App endpoints to facilitate commissioning of a Phone App made by the same vendor as the Content App. If the accounts match, then the Content App may return a Setup PIN that can be used