

Value	Name	Conformance
0x0B	ContentsMenu	M
0x0C	FavoriteMenu	M
0x0D	Exit	M
0x10	MediaTopMenu	M
0x11	MediaContextSensitiveMenu	M
0x1D	NumberEntryMode	M
0x1E	Number11	M
0x1F	Number12	M
0x20	Number0OrNumber10	M
0x21	Numbers1	M
0x22	Numbers2	M
0x23	Numbers3	M
0x24	Numbers4	M
0x25	Numbers5	M
0x26	Numbers6	M
0x27	Numbers7	M
0x28	Numbers8	M
0x29	Numbers9	M
0x2A	Dot	M
0x2B	Enter	M
0x2C	Clear	M
0x2F	NextFavorite	M
0x30	ChannelUp	M
0x31	ChannelDown	M
0x32	PreviousChannel	M
0x33	SoundSelect	M
0x34	InputSelect	M
0x35	DisplayInformation	M
0x36	Help	M
0x37	PageUp	M
0x38	PageDown	M
0x40	Power	M
0x41	VolumeUp	M