

Value	Name	Conformance
0x42	VolumeDown	M
0x43	Mute	M
0x44	Play	M
0x45	Stop	M
0x46	Pause	M
0x47	Record	M
0x48	Rewind	M
0x49	FastForward	M
0x4A	Eject	M
0x4B	Forward	M
0x4C	Backward	M
0x4D	StopRecord	M
0x4E	PauseRecord	M
0x4F	Reserved	M
0x50	Angle	M
0x51	SubPicture	M
0x52	VideoOnDemand	M
0x53	ElectronicProgramGuide	M
0x54	TimerProgramming	M
0x55	InitialConfiguration	M
0x56	SelectBroadcastType	M
0x57	SelectSoundPresentation	M
0x60	PlayFunction	M
0x61	PausePlayFunction	M
0x62	RecordFunction	M
0x63	PauseRecordFunction	M
0x64	StopFunction	M
0x65	MuteFunction	M
0x66	RestoreVolumeFunction	M
0x67	TuneFunction	M
0x68	SelectMediaFunction	M
0x69	SelectAvInputFunction	M
0x6A	SelectAudioInputFunction	M