

6.10.7.11.1. Position Field

This field SHALL indicate the position (in milliseconds) in the media to seek to. In case the position falls in the middle of a frame, the server SHALL set the position to the beginning of that frame and set the SampledPosition attribute on the cluster accordingly. If the position falls before the earliest valid position or beyond the furthest valid position to which a client MAY seek back or forward to respectively, the status of SEEK_OUT_OF_RANGE SHALL be returned and no change SHALL be made to the position of the playback.

6.10.7.12. PlaybackResponse Command

This command is used to indicate the status of the command that was issued by the client.

This command SHALL be generated in response to various Playback Commands. The data for this command SHALL be as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Status	StatusEnum	desc			M
1	Data	string	any			O

6.10.7.12.1. Status Field

This field SHALL indicate the status of the command which resulted in this response.

6.10.7.12.2. Data Field

This field SHALL indicate Optional app-specific data.

6.10.7.13. ActivateAudioTrack Command

This command is used to activate a specific Audio Track for the media being played.

Upon receipt, the server SHALL set the active Audio Track to the one identified by the TrackID in the Track catalog for the streaming media. If the TrackID does not exist in the Track catalog, OR does not correspond to the streaming media OR no media is being streamed at the time of receipt of this command, the server will return an error status of INVALID_ARGUMENT.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	TrackID	string	max 32			M
1	AudioOutputIndex	uint8	all	X		AT

6.10.7.13.1. TrackID Field

This field SHALL indicate the Audio Track to activate.