

8.2.6.1.2. TargetTemperatureLevel Field

This field SHALL specify the index of the list item in the SupportedTemperatureLevels list that represents the desired temperature level setting of the server. The value of this field SHALL be between 0 and the length of the SupportedTemperatureLevels list -1.

8.2.6.1.3. Effect on Receipt

If the TargetTemperature or TargetTemperatureLevel fields of the command meet all constraints but the server is unable to execute the command at the time the command is received by the server (e.g. due to the design of a device it cannot accept a change in its temperature setting after it has begun operation), then the server SHALL respond with a status code of INVALID_IN_STATE, and discard the command.

If the TN feature is supported, on receipt of this command:

- If the STEP feature is supported and the TargetTemperature field does not meet the equality $(\text{TargetTemperature} - \text{MinTemperature}) \% \text{Step} == 0$, then the server SHALL respond with a status code of CONSTRAINT_ERROR, and the value of the TemperatureSetpoint attribute SHALL remain unchanged.
- Otherwise, the server SHALL set the TemperatureSetpoint attribute to the value of the TargetTemperature field and the response SHALL have a status code of SUCCESS.

If the TL feature is supported, on receipt of this command,

- If value of the TargetTemperatureLevel field meets all constraints, the server SHALL set its SelectedTemperatureLevel attribute to the value of TargetTemperatureLevel field and respond with status SUCCESS.
- Otherwise (e.g. if the value of the TargetTemperatureLevel field is out of bounds of the SupportedTemperatureLevels list), the status of the response SHALL be CONSTRAINT_ERROR, and the value of SelectedTemperatureLevel SHALL remain unchanged.

8.3. Dishwasher Mode Cluster

This cluster is derived from the Mode Base cluster and defines additional mode tags and name-spaced enumerated values for dishwasher devices.

8.3.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Initial revision
2	ChangeToModeResponse command: StatusText must be provided for InvalidInMode status