

ID	Name	Type	Constraint	Quality	Fallback	Conformance
1	State	StateEnum	all			M
2	Session-Duration	elapsed-s	all			M
3	SessionEnergy-Charged	energy-mWh	min 0			M
4	SessionEnergyDischarged	energy-mWh	min 0			V2X

9.3.10.2.1. SessionID Field

This field SHALL indicate the current value of the [SessionID](#) attribute.

9.3.10.2.2. State Field

This field SHALL indicate the value of the [State](#) attribute prior to the EV not being detected.

9.3.10.2.3. SessionDuration Field

This field SHALL indicate the total duration of the session, from the start of the session when the EV was plugged in, until it was unplugged.

9.3.10.2.4. SessionEnergyCharged Field

This field SHALL indicate the total amount of energy transferred from the EVSE to the EV during the session.

Note that if bi-directional charging occurs during the session, then this value SHALL only include the sum of energy transferred from the EVSE to the EV, and SHALL NOT be a net value of charging and discharging energy.

9.3.10.2.5. SessionEnergyDischarged Field

This field SHALL indicate the total amount of energy transferred from the EV to the EVSE during the session.

Note that if bi-directional discharging occurs during the session, then this value SHALL only include the sum of energy transferred from the EV to the EVSE, and SHALL NOT be a net value of charging and discharging energy.

9.3.10.3. EnergyTransferStarted Event

This event SHALL be generated whenever the EV starts charging or discharging, except when an EV has switched between charging and discharging under the control of the PowerAdjustment feature of the Device Energy Management cluster of the associated Device Energy Management device.