

| ID     | Name                  | Type | Constraint | Quality | Fallback | Access | Conformance |
|--------|-----------------------|------|------------|---------|----------|--------|-------------|
| 0x0000 | <b>SupportedModes</b> |      |            |         |          |        |             |
| 0x0001 | <b>Current-Mode</b>   |      |            |         |          |        |             |
| 0x0002 | <b>StartUp-Mode</b>   |      |            |         |          |        | X           |
| 0x0003 | <b>OnMode</b>         |      |            |         |          |        | X           |

#### 9.4.6.1. SupportedModes Attribute

At least one entry in the SupportedModes attribute SHALL include the Manual mode tag in the ModeTags field list.

Modes with entries in the SupportedModes attribute which contain multiple mode tags permitting charging or discharging under different conditions SHALL permit the charging or discharging to occur if any of the conditions are satisfied.

Modes SHALL NOT have both the Manual tag and the TimeOfUse or SolarCharging tags defined in the SupportedModes attribute.

### 9.4.7. Derived Cluster Namespace

This namespace includes definitions for data associated exclusively with the derived cluster.

#### 9.4.7.1. Mode Tags

The following table defines the base and derived-cluster-specific ModeTag values.

| Mode Tag Value | Name             |
|----------------|------------------|
| 0x0000         | <b>Auto</b>      |
| 0x0001         | <b>Quick</b>     |
| 0x0002         | <b>Quiet</b>     |
| 0x0003         | <b>LowNoise</b>  |
| 0x0004         | <b>LowEnergy</b> |
| 0x0005         | <b>Vacation</b>  |
| 0x0006         | <b>Min</b>       |
| 0x0007         | <b>Max</b>       |
| 0x0008         | <b>Night</b>     |
| 0x0009         | <b>Day</b>       |
| 0x4000         | <b>Manual</b>    |