

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0001	Current-Conditions	Electrical-GridConditionsStruct	all	X		R V	M
0x0002	Forecast-Conditions	list[ElectricalGrid-Condition-sStruct]	max 56			R V	FORE

9.13.6.1. LocalGenerationAvailable Attribute

This SHALL indicate if there is known to be local generation (for example Solar PV or Battery Storage) at the premises.

If the presence of any local generation is unknown, or cannot be determined, the value SHALL be null.

9.13.6.2. CurrentConditions Attribute

This SHALL indicate the current electricity supply conditions. If the current conditions are unknown, or cannot be determined, the value SHALL be null.

9.13.6.3. ForecastConditions Attribute

This SHALL indicate the forecast of upcoming electricity supply conditions. If the forecast is unable to be determined, this list SHALL be empty.

The list entries SHALL be in time order:

- All entries except the last one SHALL have a non-null [PeriodEnd](#).
- For all entries except the first one, [PeriodStart](#) SHALL be greater than the previous entry's [PeriodEnd](#).

9.13.7. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	CurrentConditionsChanged	INFO		V	O

9.13.7.1. CurrentConditionsChanged Event

This event SHALL be generated when the value of the [CurrentConditions](#) attribute changes.