

command.

10.2.5. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	Network-PassphraseRequest	client ⇒ server	Network-PassphraseResponse	M	M
0x01	Network-PassphraseResponse	client ⇐ server	N		M

10.2.5.1. NetworkPassphraseRequest Command

This command is used to request the current WPA-Personal passphrase or PSK associated with the Wi-Fi network provided by this device.

If the command is not executed via a CASE session, the command SHALL be rejected with a status of `UNSUPPORTED_ACCESS`.

If no primary Wi-Fi network is available (the SSID attribute is null), the command SHALL be rejected with a status of `INVALID_IN_STATE`.

Otherwise a NetworkPassphraseResponse SHALL be generated.

10.2.5.2. NetworkPassphraseResponse Command

This command SHALL be generated in response to a NetworkPassphraseRequest command. The data for this command SHALL be as follows:

ID	Name	Type	Constraint	Conformance
0x00	Passphrase	octstr	max 64	M

10.2.5.2.1. Passphrase Field

This field SHALL indicate the current WPA-Personal passphrase or PSK associated with the primary Wi-Fi network provided by this device, in one of the following formats:

- 8..63 bytes: WPA/WPA2/WPA3 passphrase.
- 64 bytes: WPA/WPA2/WPA3 raw hex PSK. Each byte SHALL be a ASCII hexadecimal digit.

This matches the formats defined for WPA networks by the Credentials field in the Network Commissioning cluster (see [\[MatterCore\]](#)).

NOTE

WPA3-Personal permits passphrases shorter than 8 or longer than 63 characters, however the Network Commissioning cluster does not currently support configuring Matter devices to connect to operational networks utilizing such a passphrase.