

Value	Name	Summary	Conformance
0	NotSupported	Two-way Talk support is absent.	M
1	HalfDuplex	Audio in one direction at a time.	M
2	FullDuplex	Audio in both directions simultaneously.	M

11.2.6.5. TriStateAutoEnum Type

This data type is derived from enum8 and is used for tri-state settings on a device, where a setting can be in one of three states, i.e., On, Off, or Automatic.

Value	Name	Summary	Conformance
0	Off	Off	M
1	On	On	M
2	Auto	Automatic Operation	M

11.2.6.6. VideoSensorParamsStruct Type

This struct is used to define a video sensor and its characteristics.

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	Sensor-Width	uint16	min 64				M
1	SensorHeight	uint16	min 64				M
2	MaxFPS	uint16	min 1				M
3	MaxH-DRFPS	uint16	1 to MaxFPS				HDR

11.2.6.6.1. SensorWidth Field

This field SHALL indicate the practical width of the video sensor in pixels. This value is used for various purposes such as resolution control, boundaries for the [Zone Management Cluster](#) and digital Pan/Tilt/Zoom commands in the [Camera AV Settings User Level Management](#).

11.2.6.6.2. SensorHeight Field

This field SHALL indicate the practical height of the video sensor in pixels. This value is used for various purposes such as resolution control, boundaries for the [Zone Management Cluster](#) and digital Pan/Tilt/Zoom commands in the [Camera AV Settings User Level Management](#).