

11.3.6. Attributes

Table 22. Camera AV Settings User Level Management Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0	MPTZPosition	MPTZStruct	all	N		R V	MPAN MTILT MZOOM
1	MaxPresets	uint8	all	F		R V	MPRESETS
2	MPTZPresets	list[MPTZPresetStruct]	max MaxPresets	N		R V	MPRESETS
3	DPTZStreams	list[DPTZStreamStruct]	all	N		R V	DPTZ
4	ZoomMax	uint8	2 to 100			R V	MZOOM
5	TiltMin	int16	-180 to 179			R V	MTILT
6	TiltMax	int16	-179 to 180			R V	MTILT
7	PanMin	int16	-180 to 179			R V	MPAN
8	PanMax	int16	-179 to 180			R V	MPAN
9	MovementState	PhysicalMovementEnum	all			R V	MPAN MTILT MZOOM

11.3.6.1. MPTZPosition Attribute

This attribute indicates the currently selected mechanical pan, tilt, and zoom position.

11.3.6.2. MaxPresets Attribute

This attribute indicates the maximum number of presets for the mechanical pan, tilt, zoom.

11.3.6.3. MPTZPresets Attribute

This attribute SHALL be a list of [MPTZPresetStruct](#). Each entry in the list contains a preset for mechanical pan, tilt, and/or zoom, the values for which are represented by an instance of an [MPTZStruct](#).

11.3.6.4. DPTZStreams Attribute

This attribute is a list of [DPTZStreamStruct](#). If a video stream is listed, it means digital movement is supported via [DPTZSetViewport](#) or [DPTZRelativeMove](#). The initial values for each Viewport entry SHALL be the values found in the global [Viewport](#).