

**11.3.6.5. ZoomMax Attribute**

This attribute SHALL indicate the maximum value for the mechanical zoom specified by the camera manufacturer that allows for increments of 1 to be noticeable. The handling of this value is implementation specific.

**11.3.6.6. TiltMin Attribute**

This attribute SHALL indicate the minimum value for the mechanical tilt specified by the camera manufacturer in angular degrees.

**11.3.6.7. TiltMax Attribute**

This attribute SHALL indicate the maximum value for the mechanical tilt specified by the camera manufacturer in angular degrees.

**11.3.6.8. PanMin Attribute**

This attribute SHALL indicate the minimum value for the mechanical pan specified by the camera manufacturer in angular degrees.

**11.3.6.9. PanMax Attribute**

This attribute SHALL indicate the maximum value for the mechanical pan specified by the camera manufacturer in angular degrees.

**11.3.6.10. MovementState Attribute**

This attribute SHALL indicate the current movement state of the camera.

**11.3.7. Commands**

| ID | Name                    | Direction       | Response | Access | Conformance          |
|----|-------------------------|-----------------|----------|--------|----------------------|
| 0  | <b>MPTZSetPosition</b>  | client ⇒ server | Y        | O      | MPAN   MTILT   MZOOM |
| 1  | <b>MPTZRelativeMove</b> | client ⇒ server | Y        | O      | MPAN   MTILT   MZOOM |
| 2  | <b>MPTZMoveToPreset</b> | client ⇒ server | Y        | O      | MPRESETS             |
| 3  | <b>MPTZSavePreset</b>   | client ⇒ server | Y        | O      | MPRESETS             |
| 4  | <b>MPTZRemovePreset</b> | client ⇒ server | Y        | O      | MPRESETS             |
| 5  | <b>DPTZSetViewport</b>  | client ⇒ server | Y        | O      | DPTZ                 |
| 6  | <b>DPTZRelativeMove</b> | client ⇒ server | Y        | O      | [DPTZ]               |