

11.3.7.6.3. Effect on Receipt

The process below SHALL be followed by the camera when receiving this command:

- If a VideoStreamID entry does not exist in [DPTZStreams](#):
 - Fail the command with the status code NOT_FOUND, and end processing with no other side-effects.
- If the requested viewport is outside of the defined allowed range:
 - Fail the command with the status code DYNAMIC_CONSTRAINT_ERROR, and end processing with no other side-effects.
- Update the entry in [DPTZStreams](#) with the requested Viewport.
- Apply the new Viewport to the requested video stream.
- Respond with the status code SUCCESS

11.3.7.7. DPTZRelativeMove Command

This command SHALL change the per stream viewport by the amount specified in a relative fashion. This allows for multiple users to interact with a directional arrow based user interface. It is RECOMMENDED to increment or decrement the values by 10% of the SensorWidth and SensorHeight found in [VideoSensorParams](#).

The data for this command SHALL be as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	VideoStreamID	VideoStreamIDType	all			M
1	DeltaX	int16			0	O.d+
2	DeltaY	int16			0	O.d+
3	ZoomDelta	int8	-100 to 100		0	O.d+

11.3.7.7.1. VideoStreamID Field

This field SHALL be a [VideoStreamIDType](#) representing the video stream to modify.

11.3.7.7.2. DeltaX Field

This field SHALL represent the number of pixels to move the [Viewport](#) on the X axis within the SensorWidth and SensorHeight found in [VideoSensorParams](#). A value of 0 means no movement. A negative value means move the viewport left. A positive value means move the viewport right.

11.3.7.7.3. DeltaY Field

This field SHALL represent the number of pixels to move the [Viewport](#) on the Y axis within the SensorWidth and SensorHeight found in [VideoSensorParams](#). A value of 0 means no movement. A negative value means move the viewport down. A positive value means move the viewport up.