

- Fail the command with the status code `DYNAMIC_CONSTRAINT_ERROR`, and end processing with no other side effects.
- If the `TimeControl` field is not present:
 - Look up the `MotionTimeControl` field in the in the allocated `ConnectionID` and use those values as the `TimeControl`.
- Begin transmission using the `TimeControl` values, but ignore the `BlindDuration` field.
- Generate a `PushTransportBegin` event with `ConnectionID` set to the `ConnectionID` field of this command, the `ActivationReason` field set to the `ActivationReason` field of this command and the `TriggerType` field set to `Command`.
- Asynchronously generate the `PushTransportEnd` event as normal when the `TimeControl` values indicate this transmission will end.

11.7.9.7. FindTransport Command

This command SHALL return the `Transport Configuration` for the specified push transport or all allocated transports for the fabric if null.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ConnectionID	PushTransportConnectionID	all	X		M

11.7.9.7.1. ConnectionID Field

This field SHALL be a `PushTransportConnectionID` or `NULL` representing the allocated push transport.

11.7.9.7.2. Effect on Receipt

The following process SHALL be followed when the server receives this command:

- If `ConnectionID` is null:
 - If the `CurrentConnections` list is empty:
 - Fail the command with the status code `NOT_FOUND`.
 - For each entry in `CurrentConnections`:
 - If the associated fabric of the entry matches the accessing fabric:
 - Add the full `TransportConfigurationStruct` to the resulting list.
- Else if `ConnectionID` is not null:
 - If an entry matching `ConnectionID` is not found in the `CurrentConnections` list:
 - Fail the command with the status code `NOT_FOUND`.
 - If the associated fabric of the matching list entry does not match the accessing fabric:
 - Fail the command with the status code `NOT_FOUND`.