

a value that is not contained within [InstalledChimeSounds](#) SHALL be failed with a NOT_FOUND response. Writes to this attribute while a chime is currently playing SHALL NOT affect the playback in progress and SHALL only apply starting at the next PlayChimeSound command invocation.

11.8.5.3. Enabled Attribute

This attribute SHALL indicate if chime sounds can currently be played or not, and MAY be written by the client to enable / disable playing of chime sounds.

11.8.6. Commands

ID	Name	Direction	Response	Access	Quality	Conformance
0x00	PlayChime-Sound	client ⇒ server	N	O		M

11.8.6.1. PlayChimeSound Command

This command will play the currently selected chime.

11.8.6.1.1. Effect on Receipt

The following process SHALL be followed when the server receives this command:

- If [Enabled](#) is currently false:
 - The server SHALL immediately respond with a status code of SUCCESS, and end processing with no other side-effects.
- If a chime sound is currently being played:
 - The server SHALL immediately respond with a status code of SUCCESS, and end processing with no other side-effects.
- Play the chime sound associated with [SelectedChime](#)