

2.5.2. Classification

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x0013	Bridged Node		Utility	Endpoint

2.5.3. Conditions

This device type MAY support the following conformance conditions as defined below.

Condition	Description
FabricSynchronizedNode	See description below.

See the Base Device Type definition for additional conformance tags.

2.5.3.1. FabricSynchronizedNode Condition

The FabricSynchronizedNode condition applies to a Bridged Node endpoint when all of the following are true:

- There is a Commissioner Control Cluster on an Aggregator which has this endpoint as a descendant.
- The Commissioner Control Cluster has a SupportedDeviceCategories attribute with the Fabric-Synchronization bit set.
- The bridged node is a Matter Node.

2.5.4. Device Type Requirements

This device type SHALL only be indicated on endpoints which are listed in the Descriptor cluster PartsList of another endpoint with an Aggregator device type.

The table lists other device types to be implemented along with this device type based on conformance.

Device Type ID	Device Type Name	Constraint	Conformance
0x0011	Power Source		0

2.5.5. Cluster Requirements

Each endpoint supporting this device type SHALL include these clusters based on the conformance defined below.

Cluster ID	Cluster Name	Client/Server	Quality	Conformance
0x002E	Power Source Configuration	Server		BridgedPowerSourceInfo, D