

Cluster ID	Cluster Name	Client/Server	Quality	Conformance
0x0031	Network Commissioning	Server		M
0x0035	Thread Network Diagnostics	Server		[Thread]
0x0036	Wi-Fi Network Diagnostics	Server		[Wi-Fi]
0x0037	Ethernet Network Diagnostics	Server		[Ethernet]

NOTE

The Network Diagnostics cluster present in this device type SHALL serve the secondary network interface as specified in the Network Commissioning cluster.

2.9. Joint Fabric Administrator Device Type

A Joint Fabric Administrator device provides capabilities to manage the Joint Fabric Datastore and issue an ICAC signed by the Joint Fabric Anchor Root CA.

A client wanting to access the capabilities of the Joint Fabric Administrator MAY use the Joint Commissioning Method (as specified in the [Matter core specification](#)) to be commissioned onto the Joint Fabric. Once commissioned, a client MAY access the capabilities of the Joint Fabric Administrator.

2.9.1. Joint Fabric Architecture

See the Joint Fabric section of the Multiple Fabrics chapter in the [Matter core specification](#) for more information on the Joint Fabric architecture.

2.9.2. Revision History

Revision	Description
1	Initial revision

2.9.3. Classification

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x0130	Joint Fabric Administrator		Utility	Endpoint

2.9.4. Cluster Requirements

Each endpoint supporting the Joint Fabric Administrator device type SHALL include these clusters based on the conformance defined below.