

Cluster ID	Cluster Name	Client/Server	Quality	Conformance
0x0003	Identify	Server		M
0x0004	Groups	Server		O
0x0006	On/Off	Server		O
0x0071	HEPA Filter Monitoring	Server		O
0x0072	Activated Carbon Filter Monitoring	Server		O
0x0202	Fan Control	Server		M

9.3.6. Cluster Restrictions

9.3.6.1. On/Off Cluster (Server) Clarifications

The On/Off cluster is independent from the Fan Control Cluster's FanMode attribute, which also includes an **Off** setting.

If the **FanMode** attribute of the Fan Control cluster is set to a value other than **Off** when the OnOff attribute of the On/Off cluster transitions from TRUE to FALSE, it may be desirable to restore the **FanMode**, **SpeedSetting** and **PercentSetting** attribute values of the Fan Control cluster when the OnOff attribute of the On/Off cluster later transitions from FALSE to TRUE. If the **FanMode** is set to **Off** when the device is turned off, this information is lost, as the **SpeedSetting** and **PercentSetting** will be set to zero. Using the On/Off cluster alongside the Fan Control cluster allows the **FanMode**, **SpeedSetting** and **PercentSetting** to remain unchanged when the device is turned off. In this case, the On/Off cluster would be set to **Off**, and the **SpeedCurrent** and **PercentCurrent** set to zero, without changing **FanMode**, **SpeedSetting** and **PercentSetting**.

9.4. Thermostat Controller Device Type

A Thermostat Controller is a device capable of controlling a Thermostat.

9.4.1. Revision History

Revision	Description
1	Initial Matter revision

9.4.2. Classification

Device Type ID	Device Type Name	Superset Of	Class	Scope
0x030A	Thermostat Controller		Simple	Endpoint