

URI	<BaseURL>/v1/dist/setClientInfo
Method	POST
Example Request (URI)	http://{host}/YamahaExtendedControl/v1/dist/setClientInfo
Example Request (json)	{ "group_id":"9A237BF5AB80ED3C7251DFF49825CA42", "zone":["main", "zone2"] }

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

5.4. startDistribution

For initiating Link distribution. This is valid to a Device that is setup as Link distribution server.

Request Parameters

name	type	required	description
num	integer	yes	Specifies Link distribution number on current MusicCast Network

URI	<BaseURL>/v1/dist/startDistribution?num=<num>
Method	GET
Example Request	http://{host}/YamahaExtendedControl/v1/dist/startDistribution?num=2

Response Parameters

name	type	description
response_code	integer	0: Successful request / Others: Error Refer to " Response Code List " for details

Example Response	{ "response_code":0 }
------------------	-----------------------------

5.5. stopDistribution

For quitting Link distribution. This is valid to a Device that is setup as Link distribution server.