

7. All ID List

Type	ID
Zone	main / zone2 / zone3 / zone4 ※Zone A is handles as "main", Zone B is handles as "zone2"
Input	cd / tuner / multi_ch / phono / hdmi1 / hdmi2 / hdmi3 / hdmi4 / hdmi5 / hdmi6 / hdmi7 / hdmi8 / hdmi / av1 / av2 / av3 / av4 / av5 / av6 / av7 / v_aux / aux1 / aux2 / aux / audio1 / audio2 / audio3 / audio4 / audio5 / audio_cd / audio / optical1 / optical2 / optical / coaxial1 / coaxial2 / coaxial / digital1 / digital2 / digital / line1 / line2 / line3 / line_cd / analog / tv / bd_dvd / usb_dac / usb / bluetooth / server / net_radio / napster / pandora / siriusxm / spotify / juke / airplay / radiko / qobuz / tidal / deezer / mc_link / main_sync / none
Sound Program	munich_a / munich_b / munich / frankfurt / stuttgart / vienna / amsterdam / usa_a / usa_b / tokyo / freiburg / royaumont / chamber / concert / village_gate / village_vanguard / warehouse_loft / cellar_club / jazz_club / roxy_theatre / bottom_line / arena / sports / action_game / roleplaying_game / game / music_video / music / recital_opera / pavilion / disco / standard / spectacle / sci-fi / adventure / drama / talk_show / tv_program / mono_movie / movie / enhanced / 2ch_stereo / 5ch_stereo / 7ch_stereo / 9ch_stereo / 11ch_stereo / stereo / surr_decoder / my_surround / target / straight / off