

4.3.1.6. TXT key for Vendor ID and Product ID (VP)

The optional key **VP**, if present, MAY provide [Vendor ID](#) and [Product ID](#) information of the device.

A vendor MAY choose not to include it at all, for privacy reasons.

If the **VP** key is present then it MAY take two forms:

1. **VP=123** gives Vendor ID
2. **VP=123+456** gives Vendor ID + Product ID

The Vendor ID and Product ID SHALL both be expressed as variable-length decimal numbers, encoded as ASCII text, omitting any leading zeroes, and of maximum length of 5 characters each to fit their 16-bit numerical range.

If the Product ID is present, it SHALL be separated from the Vendor ID using a '+' character.

If the **VP** key is present without a Product ID, the value SHALL contain only the Vendor ID alone, with no '+' character.

If the **VP** key is present, the value SHALL contain at least the Vendor ID.

If the **VP** key is present, it SHALL NOT have a missing or empty value.

4.3.1.7. TXT key for commissioning mode (CM)

The key **CM** (Commissioning Mode) SHALL indicate whether or not the publisher of the record is currently in Commissioning Mode and available for immediate commissioning. When in commissioning mode, the value associated with the **CM** key indicates the source of the Passcode.

Five situations are legal:

1. The absence of key **CM** SHALL imply a value of 0 (**CM=0**).
2. The key/value pair **CM=0** SHALL indicate that the publisher is not currently in Commissioning Mode.
3. The key/value pair **CM=1** SHALL indicate that the publisher is currently in Commissioning Mode and requires use of a Passcode for commissioning provided by the Commissionee (e.g., embedded in Onboarding Material which is printed on device, on a label or displayed on screen), such as when the device is in a factory-new state or when the [OpenBasicCommissioningWindow](#) command has been used to enter commissioning mode.
4. The key/value pair **CM=2** SHALL indicate that the publisher is currently in Commissioning Mode and requires use of a dynamically generated Passcode for commissioning corresponding to the verifier that was passed to the device using the [OpenCommissioningWindow](#) command.
5. The key/value pair **CM=3** SHALL indicate that the publisher is currently in [Joint Fabric](#) Commissioning Mode and requires use of a dynamically generated Passcode for commissioning corresponding to the verifier that was passed to the device using the [OpenJointCommissioningWindow](#) command. The rationale for this value is to allow a Commissioner to distinguish between a Commissionee that is in [Joint Fabric](#) Commissioning Mode and one that is in Commissioning Mode **CM=2**. [Joint Fabric](#) commissioning requires the execution of additional mutual verification