

4.9.4. Privacy Processing of Incoming Messages

To deobfuscate a private message received by [Section 4.7.2, “Message Reception”](#) with a given Privacy Key, perform security processing as follows:

1. If **P Flag** is not set, do nothing.
2. With the given Privacy Key, execute the decryption as specified in [Section 3.7.2, “Privacy decryption”](#) with the following instantiations:
 - a. The bit string key *K* SHALL be the Privacy Key obtained from step 1;
 - b. The MIC SHALL be the last **CRYPTO_AEAD_MIC_LENGTH_BYTES** bytes of the **C** outcome of the message security protection as specified in [Section 4.8.3, “Security Processing of Incoming Messages”](#) (**MIC** = **C**[(**CRYPTO_AEAD_MIC_LENGTH_BYTES**-1)..0])
 - c. The nonce *N* SHALL be the **PrivacyNonce** of the message.
 - d. The parameter *CP* SHALL be the message header fields where optional fields are only present in *CP* if they are present in the message:

CP = Message Counter || [Source ID] || [Destination ID]

- e. **M** = **Crypto_Privacy_Decrypt**(**K**, **CP**, **N**)
3. Let *M* be the deobfuscated output from step 2.
 - a. *M* SHALL be used in the final private message in place of the message header fields.
 - b. The first successfully validated message, *M*, by [Section 4.8.3, “Security Processing of Incoming Messages”](#) SHALL terminate iteration through Privacy Keys in step 2.

4.10. Message Exchanges

An Exchange provides a way to group related messages together, organize communication flows, and enable higher levels of the communication stack to track semantically relevant groupings of messages.

An Exchange SHALL be bound to exactly one underlying session that will transport all associated Exchange messages for the life of that Exchange. The underlying session SHALL be one of the following session types: **secure unicast** (as established by PASE or CASE), **unsecured** (as is used for the initial session establishment phase of a PASE/CASE session), **secure group**, or **MCSP**.

When used with **reliability**, Exchanges assume basic flow control by the upper layer. The Exchange Layer SHALL NOT accept a message from the upper layer when there is an outbound reliable message pending on the same Exchange.

4.10.1. Exchange Role

The first Node to send a message in an Exchange is said to be in the Initiator role, and all the other Nodes that subsequently participate in the Exchange are said to be in a Responder role. An Exchange is always between one Initiator and one or more peer Responder Nodes. An Exchange