

4.13.1. Session Parameters

This is a glossary of the session parameters used during session establishment with a brief description for each parameter. A Node SHALL use the provided default value for each parameter unless the message recipient Node advertises an alternate value for the parameter via Operational Discovery.

Table 23. Glossary of Session parameters

Parameter Name	Description	Default Value
<i>SESSION_IDLE_INTERVAL</i>	Minimum amount of time between sender retries when the destination node is Idle. This SHALL be greater than or equal to the maximum amount of time a node may be non-responsive to incoming messages when Idle.	500 milliseconds
<i>SESSION_ACTIVE_INTERVAL</i>	Minimum amount of time between sender retries when the destination node is Active. This SHALL be greater than or equal to the maximum amount of time a node may be non-responsive to incoming messages when Active.	300 milliseconds
<i>SESSION_ACTIVE_THRESHOLD</i>	Minimum amount of time the node SHOULD stay active after network activity.	4000 milliseconds
<i>DATA_MODEL_REVISION</i>	Version of Data Model for the Session parameters side where it appears.	See Section 11.1.5.1, “Data-ModelRevision Attribute” .
<i>INTERACTION_MODEL_REVISION</i>	Version of Interaction Model for the Session parameters side where it appears.	See Section 8.1.1, “Revision History” .
<i>SPECIFICATION_VERSION</i>	Version of Specification for the Session parameters side where it appears.	See Section 11.1.5.22, “Specification-Version Attribute” .
<i>MAX_PATHS_PER_INVOKE</i>	The maximum number of elements in the InvokeRequests list that the Node is able to process	See Section 11.1.5.23, “MaxPathsPer-Invoke Attribute” .
<i>SUPPORTED_TRANSPORTS</i>	A bitmap of the supported transport protocols in addition to MRP .	See Table 7, “Supported Transport Mode Values” .