

- c. The **P Flag** SHALL be set to **1**.
 - d. The **C Flag** SHALL be set to **1**.
 - e. The **Session Type** field SHALL be set to **1**.
 - f. The **Session ID** field SHALL be set to the **Group Session Id** for the operational group key being synchronized.
 - g. The **Source Node ID** field SHALL be set to the Node ID of the sender Node.
 - h. The **Destination Node ID** field SHALL be set to the **Source Node ID** of the *MsgCounterSyncReq*.
2. Set the **MsgCounterSyncRsp** payload fields as follows:
 - a. The *Response* field SHALL be set to the value of the *Challenge* field from the *MsgCounterSyncReq*.
 - b. The *Synchronized Counter* field SHALL be set to the current **Global Group Encrypted Data Message Counter** of the sender.
 3. Use the same **exchange context** as the *MsgCounterSyncReq* being responded to.
 - a. The **Exchange ID** of the message SHALL be set to the *Exchange ID* of the *MsgCounterSyncReq*.
 - b. The **I Flag** SHALL be set to **0**.
 - c. The **A Flag** SHALL be set to **1**.
 - d. The **R Flag** SHALL be set to **1**.
 4. Invoke **Section 4.7.1, “Message Transmission”** using parameters from step 1 to encrypt and then send the response message over UDP to the IPv6 unicast address of the destination.

The receiver of the *MsgCounterSyncRsp* message SHALL:

1. Verify the *MsgCounterSyncRsp* matches a previously sent *MsgCounterSyncReq*:
 - a. An active synchronization exchange SHALL exist with the source node.
 - b. The *Exchange ID* field SHALL match the *Exchange ID* used for the original *MsgCounterSyncReq* message.
 - c. The *Response* field SHALL match the *Challenge* field used for the original *MsgCounterSyncReq* message.
 - d. The **Destination Node ID** field SHALL match the **Source Node ID** of the original *MsgCounterSyncReq* message.
 - e. The **Source Node ID** field SHALL match the **Destination Node ID** of the original *MsgCounterSyncReq* message.
2. On verification failure:
 - a. Silently ignore the *MsgCounterSyncRsp* message.
3. On verification success:
 - a. Set the peer's group key data message counter to *Synchronized Counter*.
 - b. Clear the **Section 4.6.5.1, “Message Reception State”** bitmap for the peer.
 - c. Mark the peer's group key data message counter as synchronized.