



Figure 44. Overview of the UDC Protocol Commissioner Declaration message

The Commissioner is the Initiator and the Commissionee is the Recipient of the CommissionerDeclaration message.

It is assumed that the user has directed the Initiator to send the IdentificationDeclaration message to the Recipient. Upon receipt and before starting a PASE session with the Initiator, it is assumed that the Recipient will obtain DNS-SD record information (including TXT records) for the Initiator, which was either provided in the IdentificationDeclaration message or can be obtained by querying the DNS-SD records, and then prompt the user for approval and to enter its Onboarding Payload or Passcode.

5.3.2. UDC Protocol Messages

Table 65. User Directed Commissioning Protocol

Protocol Opcode	Protocol Command Name	Description
Protocol ID = PROTOCOL_ID_USER_DIRECTED_COMMISSIONING		
0x00	IdentificationDeclaration	The Identification Declaration message provides the DNS-SD Instance Name of the commissionee requesting commissioning to the commissioner selected by the user. It can also include information relating to the requested commissioning session.
0x01	CommissionerDeclaration	The Commissioner Declaration message provides information to a commissionee from the commissioner indicating its pre-commissioning state. This information can be used by the commissionee to simplify the Passcode entry flow for the user.

5.3.3. Message format

All UDC messages SHALL be structured as specified in Section 4.4, “Message Frame Format”.

All UDC messages are unsecured at the message layer:

- The Session ID field SHALL be set to 0.
- The Session Type bits of the Security Flags SHALL be set to 0.
- The S Flag and DSIZ fields of the Message Flags SHALL be set to 0.

The R Flag of the Exchange Flags for the UDC messages SHALL be set to 0.

For each UDC message, the application payload is the TLV encoding of the message structure as