

```

    Targets: []           // entire node
  }
]
}

```

During the commissioning phase, the [AddNOC](#) command automatically creates an Access Control Entry granting [Administer](#) privilege for the appropriate [CaseAdminSubject](#).

In the scenario the node is being commissioned onto a separately-administered fabric, [Administer](#) privilege is granted for the entire Node, using the appropriate CASE authenticated Subject (in this case, Node ID 0xAAAA_AAAA_AAAA_AAAA) on the appropriate Fabric (in this case, Fabric 0xFAB0_0000_0000_001D as Fabric index 1).

```

Access Control Cluster: {
  ACL: [
    0: {
      FabricIndex: 1,
      Privilege: Administer,
      AuthMode: CASE,
      Subjects: [ 0xAAAA_AAAA_AAAA_AAAA ],
      Targets: []
    }
  ]
}

```

In the scenario the node is being commissioned onto the Joint Fabric the [Administer](#) privilege SHALL be granted for all Nodes with the Administrator CAT as the [CaseAdminSubject](#) (in this case, 0xFFFF_FFFD_FFFF_0001) on the appropriate Fabric (in this case, Fabric 0xFAB0_0000_0000_001D as Fabric index 1).

```

Access Control Cluster: {
  ACL: [
    0: {
      FabricIndex: 1,
      Privilege: Administer,
      AuthMode: CASE,
      Subjects: [ 0xFFFF_FFFD_FFFF_0001 ],
      Targets: []
    }
  ]
}

```

An Administrator adds an Access Control Entry which grants [View](#) privilege, for the entire Node, to