

The Read Interaction provides a means to read the contents of all or part of a cluster.

For example, reading cluster `0x0000_ABCD` on endpoint 1 might return mandatory attribute `0x0000_0001`, optional attribute `0x0000_0009`, and MS attributes `0x000A_0001` and `0x000A_0002`.