

unspecified transaction or interaction error. This action conveys status to this layer or conveys status from this layer to another node. The status indicates success or an error as part of a transaction or interaction.

See [Section 8.2.5, “Common Action Behavior”](#) for behavior common to all actions. The specific action information for this action is shown below.

8.3.1.1. Status Response Information

Action Field	Type	Conformance	Description
Status	status	M	a status code (see Status Codes)

8.3.1.2. Outgoing Status Response Action

- This action SHALL be unicast.
- This action SHALL NOT be generated in response to a groupcast.
- This action SHALL be generated as specified in interactions defined here.
- If this action is generated with an error Status, the current transaction and interaction SHALL be terminated.
- This action SHALL only be generated with an error Status when an error occurs as a result of the immediate previous received action in the current transaction.
- This action’s DestinationNode field SHALL be the immediate previous received action’s SourceNode.
- This action’s TransactionID field SHALL be the immediate previous received action’s TransactionID.
- If there is no well-defined Status Code for an error or exception, the Status Code of FAILURE SHALL be used.

8.3.1.3. Incoming Status Response Action

- Upon receipt of this action with a success Status Code, this layer SHALL consume the status and continue the current transaction and interaction.
- Upon receipt of this action with an error Status, this layer SHALL terminate the current transaction and interaction.
- Upon receipt of this action with an error Status, this layer SHALL submit the error to the layer above.

8.4. Read Interaction

This interaction is generated when an initiator wishes to determine the value of one or more attributes or events located on a node.