

Info Field	Type	Quality	Conformance
Command	CommandDataIB		O.a
Status	CommandStatusIB		O.a

- Only one of the above fields SHALL be present.
- The Path field in [CommandDataIB](#) and [CommandStatusIB](#) SHALL indicate a concrete path.

8.9.5. Status Information Blocks and Paths

8.9.5.1. CommandStatusIB

This is used to indicate a command response that represents a status: an invalid command, an error accessing the command, successful [execution](#) of a command without a following command, and so on.

Info Field	Type	Quality	Conformance
CommandPath	CommandPathIB		M
Status	StatusIB		M
CommandRef	uint16		O

- The Path field SHALL indicate a concrete path.

CommandRef field

This field is used to provide a reference for a command.

- CommandRef MAY be omitted from the CommandStatusIB if InvokeRequests contains only a single CommandDataIB, even if CommandRef was included in that CommandDataIB.
- CommandRef SHALL be included in the CommandStatusIB in InvokeResponses if InvokeRequests contained more than one CommandDataIB.
- When a CommandStatusIB in InvokeResponses has a CommandRef field, its value SHALL be equal to the CommandRef field from the CommandDataIB (in InvokeRequests) that generated this CommandStatusIB.
 - If InvokeRequests contained only a single CommandDataIB, and CommandRef was not included in that CommandDataIB, then CommandRef for this CommandStatusIB in InvokeResponses SHALL NOT be included.

8.9.5.2. EventStatusIB

This is used to indicate an invalid event, or an error accessing the event.

Info Field	Type	Quality	Conformance
Path	EventPathIB		M
Status	StatusIB		M