

other nodes by re-assigning (reusing) an endpoint address for a *different* exposed entity. Other nodes using the exposed entities from this node SHOULD remove information related to exposed entities no longer being exposed.

Other nodes that wish to be notified of changes of the exposed entities SHOULD monitor changes of the PartsList attribute in the Descriptor cluster on the [root node endpoint](#).

9.2.11. Node Configuration Changes

A node MAY be able to support different capabilities depending on the installation or configuration of the device. Changes in capabilities MAY result in the node gaining and/or losing Matter-related functionality which could impact the representation and use of the node within the system.

Changes in the configuration of the node could impact a controller's ability to understand the capabilities of that node and the overall system, such as configured bindings with other nodes or automations in a controller/ecosystem, which could break due to the functionality no longer being present on the node.

Nodes SHALL indicate changes in their configuration that impacts the representation of the node by increasing the [ConfigurationVersion](#) attribute in the [Basic Information Cluster](#). The [ConfigurationVersion](#) SHALL also be increased in the case a firmware update adds or removes functionality on the node. For bridged nodes, this attribute is located in the corresponding [Bridged Device Basic Information Cluster](#); when such a configuration change occurs, the [ConfigurationVersion](#) attribute in the [Basic Information Cluster](#) of the bridge SHALL also be increased.

A client SHOULD detect a change of [ConfigurationVersion](#) on a node (or bridged node) and SHOULD take the necessary steps to reevaluate the capabilities of the node—these steps are manufacturer specific. The controller MAY attempt to reconfigure e.g. bindings, if required, in order to re-establish the functionality of the system. The steps required to do so are manufacturer specific.

Servers SHALL report any changes to fixed attributes in the same Report Data Action as the corresponding change to the [ConfigurationVersion](#) attribute.

Clients SHOULD wait until they have received an entire Report Data Action before acting on any changes to fixed attributes, or the [ConfigurationVersion](#) attribute.

On any changes seen either to a fixed attribute or the ConfigurationVersion attribute of the Basic Information cluster or the Bridged Basic Information cluster, clients SHOULD hold-off for some time before taking into consideration the re-computation of device topology or configuration, if their design requires it, so as to provide enough time for the server to have reported all dependent changes associated with the reconfiguration and avoid re-computing configuration changes too frequently. For example, it is not expected for a Thermostat configuration to change every second, but rather at most a few times during the installed lifetime. It would be appropriate for a client to wait for several minutes before acting on changes to fixed attributes, to ensure that the entire reconfiguration is done and avoid doing complex re-computations or data migrations of settings or bindings until it's very unlikely that further configuration changes will occur.